## **Random Screening Feature**

## For the HMI Touchscreen Controller

As an add-on feature to the HMI Touchscreen Controller, Random Screening is the newest addition to Gunnebo's industry-leading security profile. Working hand in hand with a government agency, Gunnebo developed the automated Random Screening program to help safeguard facilities and people against employees, contractors, and guests carrying prohibited items and faulty credentials.

Gunnebo Random Screening works independently of the primary turnstile access control system, programmed through the HMI Touchscreen Controller. Based on adjustable screening frequency, the turnstiles will randomly choose users passing through the turnstiles for an additional screening procedure. As a completely random check, it allows the security team to have a closer handle on what employees and visitors may be bringing in to the workplace, keeping everyone honest and on their toes.

- 1. From the *Lane 1 Menu* screen, press and hold the bottom left corner, then enter password 8520 or 32835.
- 2. The *Communications Settings Menu* shows the lanes enabled according to suite configuration. Press the lower middle button to edit Random Screening feature.
- 3. From the *Random Search Settings Menu*, you can edit the number of users at each turnstile lane to randomly screen per hour. Below that, you can edit the percentage of users of each lane to randomly screen (e.g. enter 10 for 10% of all users).

For further information, please contact:
Gunnebo Entrance Control Inc.
535 Getty Ct., Benicia, CA 94510
Tel: 513-666-4821
Email: info@gunnebo.us
www.gunneboentrancesecurity.com

LANE 1 MENU CONTROL COUNTS MAIN MENU Press and hold <u>COMMUNICATIONS</u> SETTINGS ANE 6 DISABLED DISABLED ANE 2 ANE 7 DISABLED DISABLED ANE 3 ANE 8 DISABLED DISABLED ANE 4 ANE 9 DISABLED DISABLED ANE 5 ANE 10 DISABLED MAIN MENU Lane 3 People 12345 Lane 4 People Lane 6 People 12345 12345 12345 12345 12345 12345 MAIN MENU

